



テザーツールズ USBケーブル × カメラ対応表

カメラ					USB ケーブル					
Nikon	Canon	SONY	Fujifilm	Panasonic	カメラ側端子	PC 側端子	ケーブル長	色	型番	JAN
D6 D780 Z6 Z7 Z6 Mark II Z7 Mark II	1DX Mark III R	α1 α7 III α7R III α7R IV α7S III α9 II	GFX 50R GFX 100 GFX 100S X-T3 X-T4 X-Pro3	DC-GH5 DC-GH5S DC-S1 DC-S1H DC-S1R DC-S5	USB-C	USB-C	0.9 m	●	CUC03-BLK	0818307014381
						USB-C	0.9 m	●	CUC03-ORG	0818307014374
						USB-C	3.0 m	●	CUC10-BLK	0818307014428
						USB-C	3.0 m	●	CUC10-ORG	0818307014411
						USB-C	4.6 m	●	CUC15RT-BLK	0818307012943
						USB-C	4.6 m	●	CUC15RT-ORG	0818307010994
						USB-C	4.6 m	●	CUC15-BLK	0818307014442
						USB-C	4.6 m	●	CUC15-ORG	0818307014435
						USB 3.0 対応 USB-A	0.5 m	●	CUCRT02-ORG	0818307013346
						USB 3.0 対応 USB-A	4.6 m	●	CUC3215-BLK	0818307014466
USB 3.0 対応 USB-A	4.6 m	●	CUC3215-ORG	0818307014459						
D5 D850 D810 D810A D500	1DX Mark II 5D Mark IV 5Ds 5DsR 7D Mark II		GFX 50S X-T2 X-H1	DC-G9	USB3.0 マイクロ-B	USB-C	4.6 m	●	CUC33R15-BLK	0818307014503
						USB-C	4.6 m	●	CUC33R15-ORG	0818307014497
						USB-C	4.6 m	●	CUC3315-BLK	0818307014480
						USB-C	4.6 m	●	CUC3315-ORG	0818307014473
						USB 3.0 対応 USB-A	0.5 m	●	CU61RT02-ORG	0818307015012
						USB 3.0 対応 USB-A※	4.6 m	●	CU61RT15-BLK	0818307013230
						USB 3.0 対応 USB-A※	4.6 m	●	CU61RT15-ORG	0818307013254
						USB 3.0 対応 USB-A※	4.6 m	●	CU5453	0818307010130
USB 3.0 対応 USB-A※	4.6 m	●	CU5454	0818307010147						
Z50	90D	α7 / α7 II α7R / α7R II α7S / α7S II α9 α6500 / α6600			マイクロ-B 5-ピン	USB-C	4.6 m	●	CUC2515-BLK	0818307014527
						USB-C	4.6 m	●	CUC2515-ORG	0818307014510
						USB 2.0 対応 USB-A	4.6 m	●	CU5430BLK	0818307012127
						USB 2.0 対応 USB-A	4.6 m	●	CU5430ORG	0818307012110
	6D Mark II 80D、1DX 5D Mark III 70D				ミニ-B 5-ピン	USB-C	4.6 m	●	CUC2415-BLK	0818307014541
						USB-C	4.6 m	●	CUC2415-ORG	0818307014534
						USB 2.0 対応 USB-A	4.6 m	●	CU5450	0858977002301
						USB 2.0 対応 USB-A	4.6 m	●	CU5451	0858977002950